


Imperative security precaution

The instructions for installation and use must be strictly observed in order to avoid the risk of electric shock or fire









number I1, I2 and I3 must meet the number of each measured phase

Direction of the

current indicated

L3 (phase3) = Grev

L3: A Pay attention:
L2: Respect the order
L1 of the phases indicated on the connector
L2: L2: L1

The module is powered from 100 to 240V~ between Neutral (N) and Phase 3 (V3)

A three-phases circuit breaker with a rating of C2 to C16 is required according on the section of cable used, to supply and protect the connected three-phases energy meter.


N (neutral) = Blue

ZCUC N

L1 (phase1) = Brown


Power supply

connection










* After wiring the system, replace the modular front plate, so that no active live part under tension is accessible.

(3) Finalize the installation in the Legrand Home + Control app

Download the Home + Control App and follow the instructions for adding the connected product in your setup.









www.legrand.fr/reference/412175

LEGRAND - Pro and Consumer Service - BP 30076 87002 LIMOGES CEDEX FRANCE • www.legrand.com

EU SIMPLIFIED DECLARATION OF CONFORMITY

The undersigned,

Legrand

declares that the radio equipment listed on this instruction sheet are compliant to the directive 2014/53/UE.

The full text of the EU declaration of conformity is available at the following website:

www.legrandoc.com

